



2024+ Kawasaki Ridge Packout Mount #S3318



INSTALLATION INSTRUCTIONS

2024+ Kawasaki Ridge Packout Mount



2024+ Kawasaki Ridge Packout Mount #S3318

PARTS LIST

ITEM	PART #	DESCRIPTION	QTY
	S3318	S3 Packout Mount	1
		M6 x 30mm Bolt	2
		M6 x 40mm Bolt	2
		M6 Flat Washer	4
		3/8" Spacer	2
		10 Gauge Spacer	1

- 1.) Place your Ridge on flat ground and ensure machine is in park (P).
- 2.) Start by choosing a side to install your packout on.
- 3.) On your chosen side, remove the two bolts near the side wall of the bed, as well as the two bolts towards the middle of the bed, using an 10mm socket. Keep the washers, spacers, and tiedown hooks close at hand.
- 4.) Place the two 3/8" Spacers above the holes towards the middle of the bed. Place the 10 Ga Spacer on the hole near the side wall that is closest to the tailgate.
- 5.) Place your new S3 Packout Mount into place.
- 6.) Place the factory black washers through the Packout Mount and 3/8" Spacers. Fit the factory silver spacers through the Packout Mount Tabs towards the side wall of the bed. Place your tiedown hooks above the silver spacers.
- 7.) Bolt down your Packout Mount using the 40mm bolts towards the middle of the bed and the 30mm bolts towards the side wall of the bed.
- 8.) Test Drive your Ridge and ensure that all hardware stays tight.

Thank you for choosing S3 Power Sports. Let us know if you have any questions.